

AP-MNT-D Mount Kit

Installation Guide

The AP-MNT-D is a low-profile mount kit for attaching APs or Bridges to the ceiling or wall. The low-profile design means that there will be limited space between the back of the device (APs or Bridges) and the mount surface. This mount kit is designed to work with the pre-assembled bracket on the back of the device. The AP-MNT-D is one of multiple AP-MNT mount kits.



A #1 Phillips Head screwdriver is required for installation. Screws used for installation are not provided in this kit. Install one (1) #6 1¹/₄ screw (at least 3³/₄" thread, self-tapping) of the appropriate substrate into a stud in the wall and three (3) drywall anchors and screws rated minimum 20 lbs each. For all mounting surfaces, use appropriate screws and anchors rated 20 lbs each. If your mounting bracket has a center hole, it is for alignment uses only. A screw is not required for this part of the mounting bracket.


Wall and Ceiling Installation



This mount kit supports multiple AP models. All installation images show the AP-535.


1. Use the drill template to pre-drill the holes for the AP-MNT-D mount into the wall or ceiling.
2. Screw the mount into place, making sure that the open edge is on the left-hand side with the tab on top (see [Figure 1](#)).

Figure 1 Attach Mount to Wall or Ceiling




3. Connect the two mount brackets by bringing in the bracket without the plastic rivet at an angle and clicking it into place, making sure the hemmed edges are facing the same way (see [Figure 2](#)).

Figure 2 Connect Wall Brackets




- Slide the hooked edge of the mount brackets into the wall or ceiling mount (see [Figure 3](#)).

Figure 3 *Attach Brackets to Wall Mount*




- Slide the device onto the mount starting from the left-hand side (see [Figure 4](#)).

Figure 4 *Slide AP onto Wall*



- Use the hook tool provided to pull the lock ring and slide the device fully into place and release the lock ring (see [Figure 5](#)).

Figure 5 *Lock the AP in Place*



- Use a #1 Phillips-head screwdriver to tighten the security screw (see [Figure 6](#)).

Figure 6 *Tighten Security Screw*

